


ES350/260 /250/200




LHD
2018-6




ES 350
ES 260
ES 250
ES 200

	点火 / 电源开关		保险丝盒		12V 蓄电池
	空气囊 (包含充气装置)		充气装置		燃油箱
	充气减震器		座椅安全带张紧器 (气体发生器)		结构加强件
	空气囊电脑	-	-	-	-
-	-	-	-	-	-


禁用车辆




或



操作12V 蓄电池



拖车信息



更多详情，请参考“紧急救援指南”。

<http://www.toyota.co.jp/#####/>